

IC-91AD 5W Dual Band Transceiver with D-Star Capability

#### **Chargers**

BC139 Desktop charger (includes BC145SV)

BC145SV AC adaptor for BC139

BC167SV AC adaptor 12V/500mA (as supplied)

CP19 Cigarette lighter cable

CP12L Cigarette lighter cable

OPC-254L DC cord for use with an external power supply (with fuse)

#### **Batteries**

BP216 Battery case for 2 x AA batteries

BP217 Li-Ion 7.4V/1300mAh battery

#### **Remote Audio Options**

HS85 PTT/VOX headset

#### **Earphone**

SP13 Earphone

#### **Programming Equipment**

RS91 Remote control capability software (supplied with OPC-1529R)

OPC-474 Programming cable (Tr ->Tr)

OPC-1529R Programming cable (Req RS91)

#### **Digital Unit**

UT121 Digital unit. Provides D-Star capability (pre-installed)

#### **Speaker Microphone**

HM75A Remote control speaker microphone

HM128 Ear-piece style speaker/microphone with PTT. Straight entry

HM131 Remote speaker/microphone. Straight entry

HM153 Ear piece style microphone with PTT. Straight entry

#### **Carry Case**

LC163 Helps protect the transceiver from scratches

#### **Antenna**

AD92SMA SMA to BNC antenna adaptor